



HOW DO I MAINTAIN AND SET UP MY BELT DRIVE?

Installation guide – Editor / Hyde Race.

Caution: Incorrect handling can cause breakage of carbon fibres inside the belt.

1. Remove the slider on the drive-side dropout.
2. Open the rear triangle and slide the belt through.
3. Close the frame and reattach the slider.
4. Loosen the sliders on both sides and push them to the front (loosen the adjustment screw)
5. Replace the rear wheel and carefully load the belt.
6. Set the belt tension, correct rear wheel position and belt position on the sprocket using the drive-side and non-drive-side adjustment screws.
7. Torque both sliders to 10Nm.